

Servicing Outdoor Power Equipment Dealers Since 1984
8 McFadden Road © Easton, PA 18045 © (800) 942-2326 © https://shop.cadcodist.com/

Stinger SS2400 Super Seeder Transmission Drive Belt Replacement

The attached link is to the training video to replace the transmission drive belt on a Stinger SS2400 Super Seeder. The spring tension should be set at .070 - .080 between the gaps in the tension spring. (The thickness of a nickel should just fit in between the gaps in the tension spring.)

https://youtu.be/Uy4ez8OUQLo?si=WBW1SYEJ8EZrCIhW

TRANSMISSION BELT ASM - SUPER SEEDER



