Qı	uick	Setup List Model: Serial Number:		
Set	up Proc		nician Sign-off	Warranty
1		Uncrate the unit.		[_]
2		Connect the battery cables.		[_]
3		Raise the roll bar.		[_]
4		Install the roll bar safety decals (export models only).		[_]
5		Check/Fill the engine oil level.		[_]
6		Check/Fill the engine coolant level.		[_]
7		Check/Fill the transmission oil level.		[_]
8		Check tire pressures.		[_]
9		Check the mower blade bolt torque.		[_]
10		Check the short right hand deck belt.		[_]
11		Check the long left hand deck belt.		[_]
12		Check wheel lug nuts & axle hub nut		[_]
13		Check the deck lift rod timing.		[_]
14		Check and level the mower deck.		[_]
15		Lubricate all grease and oil points.		[_]
16		Check/Add fuel.		[_]
17		Start the engine.		[_]
PEF	RFORM	I THE SAFETY CHECKS		
18		Check for LOOSE HARDWARE.		[_]
19		Check all OPERATOR CONTROLS.		[_]

Ferris is a registered trademark of Briggs & Stratton.

the online product registration form.

1-4 - Self-explanatory.

Register Product

20

5 - Make sure you use the proper oil recommendations according to starting temperatures.

Perform SAFETY INTERLOCK SYSTEM CHECK

- 6 Use the proper engine coolant.
- 7 Use the proper hydraulic oil for the drive system. Mobil One 15W-50 or Castrol Syntec 5W-50 Synthetic Motor Oil.
- 8 Front tire pressure 25psi, rear tire pressure 15psi.
- 9 Torque blade bolt to 120-135 ft-lbs. Blade bolt wrench size is 15/16". Spindle pulley taper lock bolt torque is 108 in-lbs.
- 10 Spring tension length is 6 3/8" (+/- 1/8").
- 11 Set main deck belt tension with deck set at 3 1/2". Spring tension length is 10 1/4" (+/- 1/8").
- 12 Check/adjust suspension spring pre-load for operator comfort. Rear tires will need to be removed to adjust the rear shocks. Torque tire lug nuts to 90-95 ft-lbs. Torque axle hub nut to 200 ft-lbs PLUS rotation to align cotter pin.
- 13 Check inner rod, bolt center to bolt center, and compare to inner lift pivots. (1/8" variance rod to pivot & left side to right side.) Repeat for the shorter outer rods.
- 14 Check the deck level at 4" and blades facing front to back. Front should measure 4" from level/flat surface to blade tip, rear is 4 1/4".
- 15 Particularly ensure that the front wheels, front casters and spindles are well greased. If they were not greased, please file a warranty claim.

To register the product: log onto www.thepowerportal.com, select the appropriate brand, click "Sales &

Marketing", select the "Product Registration" link, and then select "New Product Registration". Fill out and submit

- 16 Use ultra-low sulfur fuel only. Please refer to engine manufacturer's manual for specific recommendations.
- 17 Do not crank the engine continuously for more than 30 seconds.
- 18 Generally, check over the machine for loose hardware.
- 19 Adjust seat for the operator's comfort. Check/adjust ground speed, speed balance and neutral position. Check/adjust parking brake. With parking brake engaged, compressed spring length is 2 1/8".
- 20 Perform safety interlock system tests.
  - 1) No crank PTO engaged, parking brake not engaged, or ground speed control levers not in neutral.
  - 2) Engine crank PTO not engaged & parking brake engaged & ground speed controls in neutral.
  - 3) Engine shutdown operator comes off seat with PTO engaged, operator comes off seat with parking brake disengaged or ground speed control moved before releasing parking brake.
  - 4) Blade brake check mower blades and belt should come to a complete stop within seven seconds.
- 21 Check "Model Search" on the Power Portal for any bulletins. Register the machine there also. Be sure to register the CAT engine also.

 $[\_]$